PROCESS REFRACTOMETER FOR CONCENTRATION MEASUREMENT OF CHEMICALLY AGGRESSIVE LIQUIDS

VAISALA



Vaisala K-PATENTS® Process Refractometer PR-23-W/M

TYPICAL APPLICATIONS

The Saunders Body PR-23-W and Teflon Body PR-23-M Refractometers provide accurate means for measuring liquid concentrations in chemically aggressive solutions that corrode, foul or otherwise destroy metal parts as well as in ultra-pure fine chemical processes, where metal parts cannot be used.

CHLOR-ALKALI INDUSTRY

CORROSIVE CHEMICALS

ULTRA PURE FINE CHEMICALS

ELECTRONIC CHEMICALS

Acetic acid CH3COOH, Ammonium fluoride NH4F, Ammonium hydroxide NH4OH, Ammonium sulphate (NH4)2SO4

Calsium hypochlorite Ca(CIO)2, Copper chloride CuCl2, Citric acid C6H8O7, Chromic acid CrO3

Ferric chloride FeCl2, Fluosilic acid, Formic acid HCO2H

Hydrochloric acid HCl, Hydrofluoric acid HF, Hydrogen peroxide H2O2, Buffered HF (BHF), Aqua Regia HNO3/HCl

Lactic acid C2H4(OH)COOH


Magnesium chloride MgCl2, Nickel chloride NiCl2, Nitric acid $\rm HNO3$

Phosphoric acid H3PO4, Potassium carbonate K2CO3 · 11/2 H2O, Potassium hydroxide KOH, Potassium thiocyanate KSCN, Potassium nitrate KNO3

Sodium bicarbonate NaHCO3, Sodium carbonate Na2CO3, Sodium chloride NaCl, Sodium dichromate Na2Cr2O7 \cdot 2H2O, Sodium hydroxide NaOH, Sodium hypochlorite NaClO2, Sulphuric acid H2SO4 and more.







2" pipe size 3" pipe size

SAUNDERS BODY REFRACTOMETER PR-23-W

The Saunders Body Refractometer PR-23-W is designed for use in chemically aggressive solutions and ultra-pure fine chemical processes in large-scale production and in large pipelines (diameter 50, 80 or 100mm/2", 3" or 4").

The PR-23-W refractometer is delivered with a Saunders (diaphragm) valve body and can be mounted either in a vertical or horizontal pipe. The Saunders body material is Graphite cast iron, which provides a solid mechanical base for the sensor installation.

The cast iron is lined with 3mm ETFE (Ethylene tetrafluoroethylene) fluoroplastic that gives the body a high chemical resistance. The sensor wetted parts materials are Teflon® PTFE (Polytetrafluoroethylene) and Sapphire (Al $_2\mathrm{O}_3$). The material of the sensor cover is stainless steel AISI 316 L.





TEFLON BODY REFRACTOMETER PR-23-M


The Teflon Body Refractometer PR-23-M is designed for small pipe sizes.

The sensor wetted parts Teflon® PTFE or Kynar® PVDF (Polyvinylidenefluoride), Sapphire ($\mathrm{Al_2O_3}$), and Kalrez® are carefully selected because they have high chemical and mechanical resistance.


The external materials AISI 316L (sensor cover) and polyamid 6.6 (electrical connector) withstand chemically aggressive gases and splashes of the process liquid.

The measurement accuracy of either Refractometer model is not influenced by particles, bubbles, colour or temperature changes of the process liquid.


DIGITAL MEASUREMENT PRINCIPLE



The light source sends light against the interface between the prism and the process solution, where the rays meet the surface at different angles.




Depending on the angle, some rays are totally reflected. Some rays are only partially reflected, and most of the light is refracted into the process solution.



Thus an optical image with a dark sector and a light sector is created.

The angle corresponding to the shadow line is called the Critical Angle of Total Reflection. The Critical Angle is a function of the refractive index and hence the concentration of the solution.



A digital CCD-camera detects the optical image and the shadow line. The camera transforms the optical image point-by-point to an electrical signal. The exact shadow line position is located and converted to a reading in refractive index.

A built-in temperature sensor measures the temperature on the surface of the process liquid. The indicating transmitter converts the refractive index and temperature to concentration units

The diagnostics program ensures that the measurement is reliable.

OPERATION

The Refractometer PR-23-W/M sensor is factory calibrated to measure refractive index n_D and temperature T in standard units. Each sensor has identical calibration $n_D = 1.32...1.53$ (corresponding to 0-100% b.w.). One or two sensors can be connected to one Indicating transmitter.

Because the sensors have identical calibration, and each sensor gives Refractive Index $\rm n_D$ and temperature as output, all sensors can be freely interchanged without optical calibration or parameter changes.

Each sensor comes with a calibration certificate comparing a set of standard liquids to the actual sensor output. The calibration and accuracy can be easily verified on-site with certified refractive index liquids and the documented verification procedure.


REMOTE USABILITY

The PR-23-W/M ease-of-use is significantly improved by a built-in web server that can be accessed via Ethernet. It is possible to obtain a remote display with real-time measurement data and diagnostics, and remotely alter instrument configuration settings or update program versions without having to go to the field.

Only a cross-over cable and data acquisition software are needed for collecting the data from a PR-23-W/M refractometer. The communication is built on standard protocols (UDP/IP) and offer ready-to-install software for the data acquisition.


Our data acquisition software is expandable in case the user wants to modify the program. The program is written in Java and is therefore system independent. It can be tailored to almost any computing environment.

DESIGN




SPECIFICATIONS

SENSOR PR-23-W




Saunders valve body	Flange size	A	В	C	D	E	F
SVB-A020	ANSI 2" 150psi	196 [7.72]	152.4 [6]	47 [1.85]	189 [7.40]	19.1 [0.75]	120.7 [4.75]
SVB-D050	DN50 10bar	230 [9.06]	165 [6.50]	50 [1.97]	189 [7.40	18 [0.71]	125 [4.92]
SVB-J050	JIS 10k 50A		155[6.1]	61.1[2.4]		19[0.75]	120[4.72]
SVB-A030	ANSI 3" 150psi	260 [10.24]	190.5 [7.5]	78 [3.07]	205 [8.07]	19.1 [0.75]	152.4 [6]
SVB-D080	DN80 10bar	310 [12.2]	200 [7.87]	80 [3.15]	205 [8.07]	18 [0.71]	160 [6.30]
SVB-J080	JIS 10k 80A		185[7.28]	90[3.54]		19[0.75]	150[5.90]
SVB-A040	ANSI 4" 150psi	311 [12.24]	228.6 [9]	92 [3.62]	256 [10.08]	19.1 [0.75]	190.5 [7.5]
SVB-D100	DN100 10bar	350 [13.78]	220 [8.66]	100 [3.94]	256 [10.08]	18 [0.71]	180 [7.09]
SVB-J100	JIS 10k 100A		210[8.27]	115.4[4.54]		19[0.75]	175[6.89]

SENSOR PR-23-M



INDICATING TRANSMITTER DTR



Refractive Index range, standard:	Full range, n _D 1.32001.5300 (corresponds to 0100% b.w.), sapphire prism				
Refractive Index range, option:	n _p 1.26001.4700, sapphire prism				
Accuracy:	$n_{\rm D}\pm$ 0.0002, typically corresponds to \pm 0.1% b.w. Repeatability $n_{\rm D}\pm$ 0.0001, typically corresponds to \pm 0.05% b.w.)				
Speed of response:	1s undamped, damping time selectable up to 5 min				
Patented CORE-Optics:	No mechanical adjustments and digital measurement with 3648 pixel CCD element, sodium D-line light emitting diode (LED), built-in Pt-1000 temperature sensor				
Temperature compensation:	Automatic, digital compensation				
Instrument verification:	With standard n_D liquids and the documented procedure (ISO 9000)				
Ambient temperature:	Sensor: -20 °C45 °C (-4 °F113 °F); Indicating transmitter: 0 °C45 °C (32 °F122 °F)				
Process temperature:	-20 °C130 °C (-4 °F 266 °F)				
Sensor protection class:	IP67, Nema 4X				
Approvals for hazardous locations:	Non-Sparking/Non-Incendive version: ATEX certified for Zone 2 area, Ex II 3 G, EEx nA IIC T4 Gc; FM certified for Class I, Div. 2, Groups A, B, C & D hazardous locations, T6; CSA certified for Class I, Div. 2, Groups A, B, C & D, T4; IECEx certified, Ex nA IIC T4 Gc Intrinsically safe version: ATEX certified for Zone 0 area, Ex II 1 G, EEx ia IIC T4 Ga; FM certified for Class I, Div. 1, Groups A, B, C & D, T4 (for U.S.A. and Canada); IECEx certified, Ex ia IIC T4 Ga				
Approval for electrical safety:	cCSAus certified, Equipment Class I, Poll. Deg. 2 / Transmitter, Poll. Deg. 3 / Sensor, Install. Cat. II				
SENSOR PR-23-W:	Process connection with ETFE (Ethylene tetrafluoroethylene) lined Saunders (diaphragm) valve body 2", 3" or 4"; valve body material Graphite cast iron				
Saunders body process connection:	DIN-flange DN50 PN 16/DIN-flange DN80 PN 16/DIN-flange DN100 PN 16/ANSI-flange 4" 150 lbs/ANSI-flange 3" 150 lbs/ANSI-flange 2" 150 lbs / JIS-flange 10k 50A/ JIS-flange 10k 80A/ JIS-flange 10k 100A				
Sensor wetted parts:	ETFE (Ethylene tetrafluoroethylene) lining, prism gasket Teflon® PTFE, prism sapphire, O-ring Kalrez, adaptor sapphire				
Sensor weight:	with 2" Saunders body 15 kg (33 lbs)/3" 26 kg (57 lbs)/4" 33 kg (73 lbs)				
Process pressure:	max. 10 bar (145 psi)				
SENSOR PR-23-M:	Process connection with Thread G1/2" (F) or Thread NPT 1/2" (F)				
Sensor wetted parts:	Teflon® PTFE or Kynar® PVDF (Polyvinylidenefluoride), prism gasket Teflon® PTF prism sapphire, O-ring Kalrez, adaptor sapphire				
Sensor weight:	5.5 kg (12 lbs)				
INDICATING TRANSMITTER DTR:					
Display:	320x240 pixel graphical LCD with LED backlight, keypad with 8 membrane keys				
Current output:	Two independent current outputs, 4-20 mA, max. load 1000 Ohm, galvanic isolation 1500 VDC or AC (peak), hold function during prism wash				
Fieldbus and industrial Ethernet connectivity:	Through Fieldbus converter to Modbus/TCP, Modbus RTU and Ethernet/ IP networks				
Power:	AC input 100-240 VAC/50-60 Hz, optional 24 VDC, 30 VA				
Alarms/Wash relays:	Two built-in signal relays, max. 250 V/3 A				
Sensor connectivity:	One or two sensors can be connected to one DTR. Sensors independent with own parameter sets and usable in different applications. Two current outputs configurable independently to indicate process concentration or temperature of either sensor.				
Indicating transmitter weight:	transmitter weight: 4.5 kg (10 lbs)				
Transmitter protection class:	Polycarbonate enclosure IP66, Type 4X (indoor use); AISI 304 Stainless steel enclosure IP66 (Indoor use)				
INTERCONNECTING CABLE:	IEC 61158-2 compliant two-wire cable				
Interconnecting cable length:	Standard 10 m (33 ft), max. 200 m (660 ft). Cable fittings to Indicating transmitter: European cable glands M20x1.5 or US conduit hubs				
PATENTS:	See www.kpatents.com				
ORDERING INFORMATION:	 Sensor type and process connection Desired scale Properties of process solution Process temperature range 	 Process pipe size Process flow rate Supply voltage and frequency Options and accessories			



Please contact us at www.vaisala.com/requestinfo

Ref. B211889EN-A © Vaisala 2020